

Art. No. 90002

Installation Instruction for Rigid Tube Handlebar Adapters

Please, install the handle bars as follows:

At first dismantle the handlebar.

Thereafter, attach the handlebar adapters with 4 x M 8x 20 Allen screws on the front of the steering head plate.

Now, insert the handlebar into the recess of the adapters, align as required and tighten them with the new clamp stands and the 2 x M 8x 35 and 2x M8x25 Allen screws with 22Nm.

Caution, important:

Please pay attention not to mix up the screws.

Apply some grease onto the screws.

Please make sure that the remaining gap is optically alike. Use washers, if necessary.

In case the brake line is a little tight, the following helps:

Remove the cap on the steering head plate. If you loosen the hex screw which is located underneath, you can slide down the standpipe and then pull through the brake line below the steering head plate.

We wish you a pleasant journey.

Your MV Team.