

Mounting Instruction R1200GS 2008 Handle Bar Adapter

First remove both clamp bucks and thereafter both handle bar risers.

Now attach the MV adapters into the open hollows and slightly tighten the M10 screw.

Then put the handle bar into the adapter, align them and add both clamp bucks.

Start to attach both M8 front screws and tighten them. And then both rear screws, therewith, the handle bar adapter will be set tight.

Finally, tighten the M10 screws mentioned under item 2.

Your MV-Team

MV Motorrad-Technik GmbH
Energiesstr. 3
41751 Viersen (Mackenstein)
Germany

Tel. 0049 (0) 21 62 – 32 5 64
Fax 0049 (0) 21 62 – 34 5 82
Mail: mail@verholen.de